

1 FIRST FUEL & PROPANE

Our family has your family covered.®

1000 GALLON UNDERGROUND PROPANE TANK INSTALLATION GUIDE

- 1. HOLE DIMENSIONS: 19' LONG 4.5' WIDE AND 5' DEEP WITH 5" BEDDED SAND**
- 2. PLACE TANK IN HOLE. VERIFY PROPER DEPTH WITH REDLINE MARKED ON THE NECK OF TANK**
- 3. PLACE ANODE BAG AT END OR SIDE WITH A MINIMUM DISTANCE OF 12"**
- 4. PLACE HOOD IN PROPER POSITION ON TANK AND BACKFILL THE ENTIRE TANK WITH SAND IMMEDIATELY**
- 5. FINAL GRADE MUST NOT EXCEED THE REDLINE ON TANK NECK**



CALL WITH ANY QUESTIONS 518-828-8700

